

Natural Action Technology (NAT) product instruction sheet

(DE) Whole House Structured Water Unit Installation:

1. Installation should comply with the requirements of AS 3500 and be installed by a qualified plumber.
2. Locate the main water shut off before starting. This unit can be mounted in any position, with the water entering from either end.
3. Water pressure up to 2000 kPa (300 psi)
4. Avoid dropping this unit as it may result in impaired function.



Note: when moving from your existing home to a new location, a Natural Action Technologies Blank Unit is available for purchase to replace your House Unit thereby keeping the pipeline intact. The Blank Unit looks identical and connects as described herein.

Warrantee:

This unit comes with a 20 year Manufacturing Warranty against manufacturer defects. Misuse of the unit is not covered. Avoid leaving this unit in freezing temperatures with residual water inside and avoid running boiling water through it continuously as impaired function may result.

If unit is buried in dirt or exposed to rain, the steel connectors and any brass fittings must be covered or sealed from the dirt, as nature will break down the steel and brass. Cover with several wraps of duct tape or other weatherproof wrapping.

We recommend flushing your water heater before installation by following your manufactures guidelines. The water heater may need to be flushed weekly until all loosened deposits are flushed out.

Installation questions:

Please call the office of AHA Structured Water:
Office: +61 3 9015 4170 or Mobile: 0404 109 236